

Instructions of Use:

- 1 Remove valve core from the Presta valve.
- 2 Attach Valve Extender.

